



# UT Water Treatment

<b>UT Water Treatment</b>	Formulated to enhance the properties of water as an ultrasonic coupling medium.
	<b>Key Benefits</b>
<b>Echonox® I Corrosion Inhibitor</b>	<ul style="list-style-type: none"> <li>• Good ferrous corrosion (rust) inhibitor, compatible with most metals, can provide long-term protection</li> <li>• Concentrated liquid to reduce shipping costs</li> <li>• Compatible with Echowet</li> <li>• 1 gallon treats 65 to 130 gallons of water</li> <li>• Recommended disposal: municipal sewer</li> <li>• Concentration Needed: 0.75 - 1.5%</li> </ul>
<b>Echonox® II Corrosion Inhibitor</b>	<ul style="list-style-type: none"> <li>• Most effective ferrous corrosion (rust) inhibitor for ferrous metals, can provide long term protection</li> <li>• Concentrated liquid to reduce shipping costs</li> <li>• Compatible with Echowet</li> <li>• 1 gallon treats 65 to 130 gallons of water</li> <li>• Recommended disposal: municipal sewer</li> <li>• Concentration Needed: 0.75 - 1.5%</li> </ul>
<b>Echowet® Wetting Agent</b>	<ul style="list-style-type: none"> <li>• Reduces surface tension and eliminates trapped air</li> <li>• Reduces the need to heat immersion bath or allow bath to deair</li> <li>• Lowers interfacial tension between oil and water, improving wetting of oily parts and reducing air bubbles that cling to oily parts</li> <li>• Approved material per Boeing BAC5968 and BAC5980</li> <li>• Compatible with Echonox II</li> <li>• 1 gallon treats 400 to 800 gallons of water</li> <li>• Complimentary splash goggles accompany every Echowet order</li> <li>• Recommended disposal: municipal sewer</li> <li>• Concentration Needed: 0.125 - 0.25%</li> </ul>